

How to clean your cooler



As a condition of renting our coolers, and for the health and safety of your staff/family, we require that coolers are kept in a clean and hygienic condition.

Here's how you can do it at home or office.

1. Turn off and unplug cooler,
2. Remove empty bottle and drain excess water from reservoir into a container through the taps,
3. Remove lid - it should just pop off but some designs may require you to turn it first (if you are having trouble, feel free to get in touch with us and we can advise),
4. Pour 2 litres of water, with a teaspoon of unscented bleach, into the reservoir. Let sit for 5 minutes. (You can also use vinegar and water 1:1.), give the inside of the reservoir a gentle scrub if required,
5. Run water out through both taps into an empty container,
6. Flush at least another 2 litres of plain water through until you are happy with the quality of the water,
7. Remove drip tray, wash, dry, and replace,
8. Wipe entire unit over with a damp cloth and a splash of vinegar, ensure the back of the cooler remains free of dust to ensure adequate cooling,
9. Replace new bottle,
10. Turn cooler on and leave for 10 minutes to cool,
11. Enjoy fresh, pristine spring water.

You can do this every time you get a delivery, or at least once every 3 months.



100% AUSTRALIAN
Owned & Operated

sales@babindasprings.com.au



100% NATURAL
Pure Spring Water

07 4067 1000



DIRECTLY FROM OUR SPRING
Bottled only at the source

www.babindasprings.com.au